

CHECK BEING PERFORMED: Custom

ZONES: 150
 A/C NUMBER:
 REV. DATE: 04/24/06
 FREQUENCY: 1C

W/C NUMBER: 212I2501
 DATE:
 W/O:
 JAC CODE:

REFERENCES

SEE REFERENCES AT INDIVIDUAL STEPS

MECH	INSP
	MRB ITEM: 25-999G
	AFT CARGO LOADING SYSTEM UNDERFLOOR INSPECTION
	1. PERFORM AN INSPECTION OF THE AFT CARGO COMPARTMENT FLOOR
	DIRECTLY UNDER THE CARGO LOADING SYSTEM.
	A. Access the aft cargo compartment floor directly
	under the cargo loading system.
	XXXXX (1) Remove the aft cargo compartment moveable
	bulkhead, reference AMM Task 25-53-01-254-001.
	XXXXX (2) Remove the aft cargo compartment side guide,
	reference AMM Task 25-53-02-254-001.
	XXXXX (3) Remove the aft cargo compartment ramp,
	reference AMM Task 25-53-03-254-001.
	XXXXX (4) Aft cargo compartment carpet detachment,
	reference AMM Task 25-53-05-254-003.
	XXXXX (5) Remove the aft cargo compartment guide panel,
	reference AMM Task 25-53-04-254-001.
	XXXXX (6) Remove the aft cargo compartment support panel,
	reference AMM Task 25-53-04-254-010.
	XXXXX (7) Remove the aft cargo compartment flexdown
	support system reference AMM Task 25-53-08-254-002.
	XXXXX B. Clean the aft cargo compartment floor and transition
	panels normally covered by the cargo loading system.
	XXXXX C. Perform a General Visual Inspection (GVI) of the cargo
	compartment floor and transition panels normally covered
	by the cargo loading system.
	XXXXX D. Perform a GVI of all cargo loading system components.
	E. Reinstall the aft cargo loading system installation.

AFT CARGO LOADING SYSTEM UNDERFLOOR INSPECTION

A/C NUMBER:

CHECK BEING PERFORMED: Cust

W/C NUMBER: 212I2501 (continued)

MECH: INSP:

-
- | _____ XXXXX (1) Apply a thin coat of corrosion inhibitor compound
| to the top of the aft cargo compartment floor
| panels accessed for inspection.

 - | _____ XXXXX (2) Install the aft cargo compartment flexdown
| support system, reference AMM Task 25-53-08-254-007.

 - | _____ XXXXX (3) Install the aft cargo compartment support panel,
| reference AMM Task 25-53-04-254-013.

 - | _____ XXXXX (4) Install the aft cargo compartment guide panel,
| reference AMM Task 25-53-04-254-004.

 - | _____ XXXXX (5) Install the aft cargo compartment side guide,
| reference AMM Task 25-53-02-254-009.

 - | _____ XXXXX (6) Aft cargo compartment carpet attachment,
| reference AMM Task 25-53-05-254-002.

 - | _____ XXXXX (7) Install the aft cargo compartment ramp,
| reference AMM Task 25-53-03-254-007.

 - | _____ XXXXX (8) Install the aft cargo compartment moveable
| bulkhead, reference AMM Task 25-53-01-254-007.

 - | _____ XXXXX (9) Perform an operational check of the cargo loading
| system, reference AMM Task 25-53-00-715-001.

*****END OF WORKCARD*****