

ATA AIRLINES, INC.

4C FLIGHT DECK SECURITY DOOR CHECKS

PAGE 1 / 2

CHECK BEING PERFORMED: Custom

ZONES: 211 212
A/C NUMBER:
REV. DATE: 12/07/04
FREQUENCY: 4C

W/C NUMBER: 221F5203 DATE:
W/O:
JAC CODE:

MECH INSP

4C FLIGHT DECK SECURITY DOOR CHECKS

MPD ITEMS: 52-51-00-5D
52-51-08-6A
52-51-08-6B

_____ XXXXX 1. Operationally Check the Flight Deck Door Decompression Panel.

A. Gain access to the forward side of the flight deck door.

B. Do these steps to do a check of the decompression panel:

(1) Do these steps to remove the decompression panel.

(a) Disconnect the strap that attaches the upper decompression panel to the flight compartment door by pulling up on the strap at the door connection.

(b) Push in on the two retractable bolts on the hinge assembly at the top or bottom of the decompression panel.

(2) Make sure that the bolts retract smoothly and completely clear the panel door frame.

(3) Make sure that the decompression panel hinges operate smoothly and without binding.

C. After decompression panel removal, contact inspection to perform step 2.

XXXXX _____ 2. Perform a Detailed Inspection of the Flight Deck Door Decompression Panel Seals for Condition and Security.

A. Check the door seal on the top, bottom, and sides of the panel frame for these abnormal conditions.

(1) Cracks

(2) Notches

4C FLIGHT DECK SECURITY DOOR CHECKS

PAGE:2 /2

A/C NUMBER:

CHECK BEING PERFORMED: Cust

W/C NUMBER: 221F5203 (continued)

MECH: INSP:

(3) Unusual wear

(4) Tears

(5) Splits

(6) Dents

_____ XXXXX 3. Install the Flight Deck Door Decompression Panel.

XXXXX _____ 4. Inspect the Flight Deck Door Decompression Panel Hinges for Condition and Security.

Note: Inspection is from the forward side of the flight deck door.

***** END OF WORKCARD *****