

ATA AIRLINES, INC.

EMERGENCY LIGHTS

PAGE 1 / 3

CHECK BEING PERFORMED: Custom

ZONES: 200
A/C NUMBER:
REV. DATE: 12/21/04
FREQUENCY: 1A

W/C NUMBER: 220M3301 DATE:
W/O:
JAC CODE:

MECH INSP

OPERATIONALLY CHECK EMERGENCY LIGHTS USING TEST SWITCHES.

NOTE: If workcard is being worked in a Line Maintenance Environment, work with B757 Line Service Check "EXTERIOR TASKS" and "INTERIOR TASKS" section.

1. The emergency lights to be tested are identified below.

TABLE 1 INTERIOR EMERGENCY LIGHTS.

* INTERIOR LIGHTS *	* LOCATION *
AISLE LIGHTS.	IN THE BULLNOSE OF THE OVERHEAD STOWAGE COMPARTMENTS.
EXIT SIGN LIGHTS.	ON THE CEILING, AND ABOVE THE EXIT DOORS.
FLIGHT DECK LIGHT.	IN THE FLIGHT COMPARTMENT ABOVE THE FIRST OBSERVER'S SEAT.
EXIT IDENTIFIERS LIGHT.	CLOSE TO THE FLOOR NEAR THE PASSENGER EXITS.
EMERGENCY ESCAPE PATH. LIGHTS.	ON THE FLOOR AT THE LEFT OF THE MAIN AISLE IN THE PASSENGER COMPARTMENT.

TABLE 2 EXTERIOR EMERGENCY LIGHTS.

* EXTERIOR LIGHTS *	* LOCATION *
EMERGENCY SLIDE LIGHTS.	AFT OF THE EXIT DOORS.

A. References.

EMERGENCY LIGHTS

A/C NUMBER:

CHECK BEING PERFORMED: Cust

W/C NUMBER: 220M3301 (continued)

MECH: INSP:

(1) 24-22-00/201, Electrical Power - Control.

B. Prepare for Test.

- _____ XXXXX (1) Apply electrical power (Ref/ 24-22-00).
- _____ XXXXX (2) Make sure the EMER LIGHTS switch on the pilot's overhead panel P5 is OFF.
- _____ XXXXX (3) Make sure the EMERGENCY LIGHTS switch on the forward attendant panel P21 is off (the switch/light is off).
- _____ XXXXX (4) Make sure these circuit breakers on the overhead panel P11 are closed:
 - (a) 11A32, INDICATOR LIGHTS 1.
 - (b) 11N35, EMERGENCY CHARGER LEFT.
 - (c) 11N36, EMERGENCY CHARGER RIGHT.

C. Operational Test.

- _____ XXXXX (1) Use the area test switches to test the interior emergency lights in Table 1 as follows:
 - (a) Push the emergency light test switch found above each left passenger cabin door.
 - 1) Make sure the applicable lights (Ref. SSM 33-51-01) come on.

NOTE: The lights will automatically go off after approximately one minute.

- _____ XXXXX (2) Momentarily put the EMERG LT. TEST SW on the nose gear interphone panel P62 in the MOM ON position to test the exterior emergency lights in Table 2.

NOTE: The EMER LT TEST SW also supplies power to the interior emergency lights in Table 1.

EMERGENCY LIGHTS

A/C NUMBER:

CHECK BEING PERFORMED: Cust

W/C NUMBER: 220M3301 (continued)

MECH: INSP:

-
- (a) Make sure all the exterior emergency lights come on.

NOTE: The lights will automatically go off after approximately one minute.

- D. Remove electrical power (Ref. 24-22-00) if it is no longer necessary.

- _____ XXXXX (1) Set the EMER LIGHTS switch on the pilot's overhead panel, P5, to the ON position.

- (a) Make sure that the switch operates the emergency lights.

- _____ XXXXX (2) Set the EMER LIGHTS switch on overhead panel, P5, to the OFF position.

*****END OF WORKCARD*****