

**ATA AIRLINES, INC.**

CARGO LOADING SYSTEM CLEANING

PAGE 1 / 2

CHECK BEING PERFORMED: Custom

ZONES:  
A/C NUMBER:  
REV. DATE: 09/14/06  
FREQUENCY: 1A

W/C NUMBER: 311Z2501      DATE:

MFR P/N	DESCRIPTION	QTY
AV30	Compound, Corrosion Inhibiting AV30	A/R
<b>MECH</b>	<b>INSP</b>	

MRB ITEM: 25-999H

CARGO LOADING SYSTEM INSPECTION/CLEANING

NOTE: This workcard is only applicable to aircraft equipped with the Cargo Loading System. If the aircraft is not equipped with the Cargo Loading System, "N/A" all workcard steps.

NOTE: If workcard is being worked in a Line Maintenance environment, work with B737 Line Service Check "Forward and Aft Cargo Compartments and Belly Loading Systems" task.

XXXXX 1. FORWARD CARGO COMPARTMENT SYSTEM

A. With cargo loading system in the full LOAD position, perform a general visual inspection of the carpet, sidewall, guides and movable bulkhead.

B. Remove all dirt, debris and foreign objects from the cargo loading system carpet and exposed drive system.

NOTE: Pay particular attention to the carpet edges, tracks and guides for evidence of wear or foreign objects.

C. Remove carpet ramp and wipe clean (Ref AMM 25-51-33, PB 401). Ensure brush is free of foreign objects and in good general condition.

D. Vacuum area exposed beneath ramp removing all foreign objects.

NOTE: Industry experience has shown that dirt and debris in this area will lead to premature carpet wear and/or system failure.

E. Reapply missing or damaged Corrosion Inhibiting Compound

A/C NUMBER:

CHECK BEING PERFORMED: Cust

W/C NUMBER: 311Z2501 (continued)

MECH: INSP:

to exposed floor panel area beneath ramp.

F. Install carpet ramp (Ref AMM 25-51-33 PB 401).

NOTE: Do not use sealant.

XXXXX 2. AFT CARGO COMPARTMENT SYSTEM

A. With cargo loading system in the full LOAD position, perform a general visual inspection of the carpet, sidewall, guides and movable bulkhead.

B. Remove all dirt, debris and foreign objects from the cargo loading system carpet and exposed drive system.

NOTE: Pay particular attention to the carpet edges, tracks and guides for evidence of wear or foreign objects.

C. Remove carpet ramp and wipe clean (Ref AMM 25-51-03, PB 401). Ensure brush is free of foreign objects and in good general condition.

D. Vacuum area exposed beneath ramp removing all foreign objects.

NOTE: Industry experience has shown that dirt and debris in this area will lead to premature carpet wear and/or system failure.

E. Reapply missing or damaged Corrosion Inhibiting Compound to exposed floor panel area beneath ramp.

F. Install carpet ramp (Ref AMM 25-51-03 PB 401).

NOTE: Do not use sealant.

\*\*\*\*\* END OF WORKCARD \*\*\*\*\*