

ATA AIRLINES, INC.

RESTORE (CLEAN) GALLEY PULL OUT TABLES

PAGE 1 / 3

CHECK BEING PERFORMED: Custom

ZONES: 222 240
 A/C NUMBER:
 REV. DATE: 05/25/06
 FREQUENCY: 2A

W/C NUMBER: 323Z2503 DATE:

MFR P/N	DESCRIPTION	QTY
TT-I-735	Alcohol, Isopropyl, Denatured	A/R
Cloth	Lint Free	A/R
Brush	Soft Bristle	A/R
RTV162	Adhesive, Silicone (or equivalent)	1
MECH	INSP	

MRB Item: 25-999F

1. Remove pull-out-tables as follows:

A. Access the back of the pull-out-table and unfasten the stop from the pull out table by removing the thumbscrew.

(1) Save the stop and thumbscrew

(2) Remove the six screws and access cover on the R/H G4B Galley to access the stop and thumbscrew.

B. Remove pull-out-tables.

_____ XXXXX (1) G2 Galley pull-out-table.

_____ XXXXX (2) L/H G4B Galley pull-out-table.

_____ XXXXX (3) R/H G4B Galley pull-out-table.

2. Clean the following components by liberally applying isopropyl alcohol TT-I-735:

A. Pull-out-table latching linkage and mechanisms

(1) Lay the table upside down and level.

(2) Thoroughly work alcohol into the linkage and mechanisms and allow to soak.

(3) Tilt table to remove excess alcohol and debris.

(4) Dry with a clean cloth.

(5) Repeat until both pusbuttons move freely.

B. Remaining accessible areas of pull-out-table.

A/C NUMBER:

CHECK BEING PERFORMED: Cust

W/C NUMBER: 323Z2503 (continued)

MECH: INSP:

C. Galley pull-out-table tracks and stop recesses.

(1) Use a brush and clean cloth moistened with alcohol.

D. Clean the table and listed components.

_____ XXXXX (1) G2 Galley pull-out-table and associated mounting hardware.

_____ XXXXX (2) L/H G4B Galley pull-out-table and associated mounting hardware.

_____ XXXXX (3) R/H G4B Galley pull-out-table and associated mounting hardware.

3. Reinstall pull-out-tables as follows:

A. Depress pull-out-table push buttons and slide into galley.

B. Attach table stop and thumbscrew removed above.

C. Reinstall tables.

_____ XXXXX (1) G2 Galley pull-out-table.

_____ XXXXX (2) L/H G4B Galley pull-out-table.

_____ XXXXX (3) R/H G4B Galley pull-out-table.

(a) Reinstall R/H G4B Galley access cover with 100 series RTV, or equivalent and six screws removed above.

4. Perform Operational Check as follows:

A. Ensure push buttons do not bind when locking or unlocking the table in the fully extended or retracted positions.

NOTE: If the push button is not in the locked position, the red paint is visible as an unlocked indicator.

B. Ensure pull-out-table does not bind during travel.

RESTORE (CLEAN) GALLEY PULL OUT TABLES

PAGE:3 /3

A/C NUMBER:

CHECK BEING PERFORMED: Cust

W/C NUMBER: 323Z2503 (continued)

MECH: INSP:

C. Operationally check tables.

_____ XXXXX (1) Forward galley pull-out-table.

_____ XXXXX (2) L/H G4B Galley pull-out-table.

_____ XXXXX (3) R/H G4B Galley pull-out-table.

***** END OF WORKCARD *****

REVISION DATE: 05/25/06

ATA AIRLINES, INC. B737-800 FLEET

W/C #: 323Z2503

DATE WORK CARD COMPLETE ___/___/___