

ZONES: 137
A/C NUMBER:
REV. DATE: 12/07/01
FREQUENCY: 4C

W/C NUMBER: 519M2401
DATE:
W/O:
JAC CODE:



PANELS

132FR
131AR

519M2401

MECH INSP

_____ XXXXX 1 REMOVE ALL AC AND DC JUNCTION BOX COVERS AND CONDUCT A VISUAL

CHECK INTERNAL AND EXTERNAL FOR INTEGRITY, CONDITION AND SECURITY OF RELAYS, FUSES, WIRING, CABLES, CLAMPS CONNECTORS AND TERMINALS. REINSTALL COVER.

_____ XXXXX 2 REMOVE JUNCTION BOX COVER FROM BATTERY RELAY BOX AND CONDUCT A

VISUAL CHECK INTERNAL AND EXTERNAL FOR INTEGRITY, CONDITION AND SECURITY OF RELAYS, FUSES, WIRING, CABLES, CLAMPS, CONNECTORS AND TERMINALS. REINSTALL COVER.

_____ XXXXX 3 GAIN ACCESS TO THE BACK SIDE OF EACH CIRCUIT BREAKER PANEL

LOCATION AND CONDUCT VISUAL CHECK FOR INTEGRITY, CONDITION AND SECURITY OF CIRCUIT BREAKERS, WIRING, CABLES, CLAMPS, CONNECTORS AND TERMINALS.

_____ XXXXX 4 INSPECT AC POWER DISTRIBUTION BOX FOR SECURITY OF "BUS POWER ON" INDICATOR LIGHT SOCKET RETENTION NUT.

| _____ XXXXX 5 INSPECT ACS TERMINAL BLOCKS, WIRING AND PROTECTIVE COVER FOR
| CONDITION AND SECURITY AND ENSURE FASTENER HEADS THAT ATTACH
| PROTECTIVE COVER TO L-ANGLES ARE PAINTED RED. (LOCATED AT STA
| 943.00, RBL 45-57) (-500 AIRCRAFT ONLY)

*****END OF WORKCARD*****