

ZONES: 123 215 216 225 W/C NUMBER: 711F2501 DATE:
 A/C NUMBER:
 REV. DATE: 06/07/07
 FREQUENCY: 1A

MECH INSP

MRB ITEM: 25-61-00-02, 25-61-00-05, 25-61-00-09, 25-61-00-13,
 25-61-00-21, 25-61-00-27

CABIN EMERGENCY EQUIPMENT CHECK

Additional Zones: 226, 231, 232, 241, 242, 251, 252, 261, 262,
 271, 272, 281, 282, 291, 292, 821, 822, 823,
 824, 825, 826, 827, 828

- _____ XXXXX 1. Check the medical kit (located aft RH side of C zone).
- A. Make sure the seal on the kit is not broken.
- B. Inspect for the expiration date.
- _____ XXXXX 2. Check all the first aid kits located throughout the cabin.
- A. Make sure the seal on the kit is not broken.
3. Do an Operational Check of the door escape slide/raft battery pack as follows:
- NOTE: If the warning light is ON prior to pressing the test switch, the battery pack may have a low charge, the wiring may be defective, or the precharge on the pressure bottle may be low. Make sure the electrical circuit is correct before replacing slide.
- A. Push the test button on slide shroud.
- (1) Make sure the warning light comes ON.
- B. Release the test button.
- (1) Make sure the warning light goes OFF.
- _____ XXXXX C. Accomplish Step 3.A. and 3.B. for the L1 door.
- _____ XXXXX D. Accomplish Step 3.A. and 3.B. for the R1 door.
- _____ XXXXX E. Accomplish Step 3.A. and 3.B. for the L2 door.
- _____ XXXXX F. Accomplish Step 3.A. and 3.B. for the R2 door.
- _____ XXXXX G. Accomplish Step 3.A. and 3.B. for the L3 door.

A/C NUMBER:

CHECK BEING PERFORMED: Cust

W/C NUMBER: 711F2501 (continued)

MECH: INSP:

-
- _____ XXXXX H. Accomplish Step 3.A. and 3.B. for the R3 door.
- _____ XXXXX I. Accomplish Step 3.A. and 3.B. for the L4 door.
- _____ XXXXX J. Accomplish Step 3.A. and 3.B. for the R4 door.
- _____ XXXXX 4. Do a Functional Check of the emergency flashlights.
- A. If applicable, check that the shield is properly mounted and secured, with the legend "PULL" oriented so that it can be easily read.
- B. Check that the LED is flashing at an interval of 3 - 6 seconds, and that it can easily be seen in normal lighting conditions. (If Installed)
5. Megaphone Operational Test/Battery Check.
- A. Disconnect the clamp and remove the Megaphone from the mounting bracket.
- B. Check the M-21 tag for presence, condition, and legibility.
- (1) Date of Next Insp./Expiration should indicate N/A.
- (2) Date of Last Inspection should indicate date of manufacture or latest bench check/overhaul, whichever occurred last.
- C. Check the M-21A tag for presence, condition, and legibility.
- NOTE: Megaphone batteries must be replaced every 18 months.
- (1) Replace batteries and annotate date of installation if:
- (a) It has been 18 months since date of last battery replacement.
- (b) Batteries are due to be replaced within 80 days.
- 1) If batteries are unavailable, contact Maintenance Control to schedule replacement.
- (2) Replacement batteries must be more than 24 months from the manufacturer's "Use By" date.

A/C NUMBER:

CHECK BEING PERFORMED: Cust

W/C NUMBER: 711F2501 (continued)

MECH: INSP:

NOTE: The "Use By" date can be found near the positive terminal of the battery.

D. Put the Microphone near your mouth while you point the Horn at the opposite end of the Aircraft.

(1) Pull the trigger while you count slowly in a clear voice.

(2) Make sure your voice can be heard clearly by another person at the opposite end of the Aircraft.

(3) If the voice output is weak, do these steps:

(a) Replace the batteries and perform this Operational Test again.

1) If the voice output remains weak, replace the Megaphone.

E. Attach the megaphone on the mounting bracket with the clamp.

F. Record accomplishment of worksteps 5.A. through 5.E. for each megaphone location.

_____ XXXXX (1) Forward megaphone.

_____ XXXXX (2) Aft megaphone.

***** END OF WORKCARD *****