

ATA AIRLINES, INC.

FORWARD CARGO COMPARTMENT AND COMPARTMENT DOOR

PAGE 1 / 2

CHECK BEING PERFORMED: Custom

ZONES: 121 122 125 126 W/C NUMBER: 211I5301 DATE:
A/C NUMBER: W/O:
REV. DATE: 08/06/04 JAC CODE:
FREQUENCY: 1C

PANELS

1251
821

REFERENCES

E.O. 757-25NS-1909

MECH INSP

FORWARD CARGO COMPARTMENT AND DOOR INSPECTION

| FAA ORDER: 8300.10

| ZONES AFFECTED: 121, 122, 125, 126, 821

| 1. PERFORM THE FOLLOWING CARGO COMPARTMENT DOOR INSPECTIONS.

|XXXX _____ A. Perform an External Surveillance of forward cargo door external skin, frame, and latches.

|XXXX _____ B. Perform a Detailed External Inspection of the forward cargo door stops and adjacent frame.

| 2. PERFORM THE FOLLOWING CARGO COMPARTMENT INSPECTIONS

|XXXX _____ A. Perform an External Surveillance of the forward cargo compartment door with door open.

|XXXX _____ B. Perform Internal Surveillance of the forward cargo compartment without removing sidewall or ceiling panels.

|XXXX _____ C. Inspect the forward cargo compartment nets for condition and security. There are three nets: the transverse net, the sidewall net, and the door net (Ref. E.O. 757-25NS-1909).

|XXXX _____ D. Perform an Internal Surveillance of the area aft of the forward cargo compartment (A/C mix bay without equipment removal).

|XXXX _____ E. Perform a General Visual Inspection (GVI) of the crew oxygen cylinder. Ensure valving, safety relief devices, mounting brackets, and associated instrumentation are secure and acceptable for

A/C NUMBER:

CHECK BEING PERFORMED: Cust

W/C NUMBER: 211I5301 (continued)

MECH: INSP:

continued safe flight.

(1) Check M-21 form. Verify that the crew oxygen cylinder has a current and legible M-21 form affixed to it.

(a) "Date of Next Insp./Expiration" should reflect an expiration of 24 years from date of manufacture.

NOTE: Cylinder must be replaced if within 20 months of 24 year life limit. If cylinder is not available, contact Mx Control to schedule replacement prior to reaching the life limit.

(b) "Date of Last Inspection" should reflect date of last hydrostatic test.

*****END OF WORKCARD*****