

DISINFECT POTABLE WATER SYSTEM

A/C NUMBER:

CHECK BEING PERFORMED: Cust

W/C NUMBER: 290M3801 (continued)

MECH: INSP:

- | Flush each toilet at least twice with a 15 second delay
| between flushes or until bleach water appears.
- | E Again fill system supply tank until water flows from the
| overflow outlet.
- | F Let bleach water stand in system for one (1) hour.
- | G Drain the bleach water from the system.
- | H Flush the system with drinkable water until bleach content
| is not objectionable.

_____ XXXXX 4 Fill potable water system to capacity.

_____ XXXXX 5 Reset lavatory water heater C/Bs on P37 and P70 panels.

|_____ XXXXX 6 Open all galley faucets (including faucets on each
| coffee maker) and lavatory water faucets (hot and cold sides).
| Let water flow until the water taste is not objectionable.

|_____ XXXXX 7 AIRPLANES WITH VACUUM WASTE SYSTEMS;
| Flush each toilet at least twice with a 15 second delay
| between flushes or until clean water appears.

|_____ XXXXX 8 Refill potable water system (Ref. AMM 12-14-01/301).

NOTE: Fill port must be capped (15-5238).

*****END OF WORKCARD*****