

ZONES: 200

W/C NUMBER: 320F2302

DATE:

A/C NUMBER:

REV. DATE: 11/01/07

FREQUENCY: 1C

MECH INSP

MRB Item: 23-999A

NOTE: N/A work steps if aircraft is not equipped with Medlink Kit located in G7 Galley, Cabinet 701.

NOTE: Three Mechanics are required for this task.

- _____ XXXXX 1. Mechanic 1 - Power up one of the VHF radios.
- A. Tune to an unused frequency.
- B. Set up the First Observer's Audio Control Panel (the Medlink station control) to transmit over the tuned VHF radios.
- | _____ XXXXX 2. Mechanic 2 - Power up a second VHF radio external to the aircraft.
- A. Tune to the frequency above.
3. Mechanic 3 - Using the Medlink Headset, transmit and wait for a response from the Mechanic operating the external VHF radio.
- _____ XXXXX A. Mechanic 1 - Make sure the incoming and outgoing transmissions are clear and intelligible, and can be heard over the sidetone on the flight deck headsets.
- (1) Make sure the sidetone is clear and intelligible.
- _____ XXXXX B. Mechanic 2 - Make sure the transmission is heard clear and intelligible on the external VHF radio.
- _____ XXXXX C. Mechanic 3 - On the Medlink headset, make sure the response transmission from the external VHF radio is clear and intelligible.
- _____ XXXXX 4. Power down and deselect VHF radios, and stow headsets.

***** END OF WORKCARD *****